



Games On Receipts

Games On Receipts prints puzzles at the bottom of the customer's receipt: mazes, sudoku and tic-tac-toe boards.

\$0.99 / month

Free trial: 30 days

Clover POS (United States and Canada)

OVERVIEW

How it works

1 Activating a pack downloads it

Mazes, Sudoku and Tic Tac Toe come as packs from PayPlaxe. **AVAILABLE** asks you to confirm with **Activate**, then downloads the pack's puzzles to the device and switches the pack on.

2 Activation applies to the whole account

Your activated packs are stored on your PayPlaxe account, not on one device. Other Clover devices apply the change the next time the app is opened: they download a pack that was activated elsewhere, and delete a pack that was switched off.

3 Printing is random by default

With the setting on, the app picks one of your activated packs at random, then a puzzle inside that pack. A pack that holds one puzzle therefore comes up as often as a pack of eleven, and the same puzzle can appear again.

4 Or you pick the puzzle

Inside a pack every puzzle has its own **PRINT** button, and tapping the card opens the puzzle full size with a green print button. Both download the puzzle again, so they need an internet connection.

5 Receipts get longer

A puzzle is a picture, so expect more paper per sale when random printing is on.

The app never replaces the Clover Register — it adds to it. Payments, taxes and reporting stay in Clover.

FEATURES

What it does

01

Ready-made packs

Mazes with 11 puzzles, **Sudoku** and **Tic Tac Toe**. A pack is activated with its **AVAILABLE** button and a confirmation.

02

Preview before printing

Every puzzle is shown as a picture. The thumbnails in the pack list are faded; tap a puzzle to see it full size.

03

Random printing

Print on receipts (random games) puts a randomly chosen puzzle on each receipt.

04

Print on demand

Each puzzle has its own **PRINT** button when you want a specific one. Printing on demand needs an internet connection.

05

Customer assignment

Assign customers in the Register app asks the cashier to attach a Clover customer to the order when the first item is rung up. The customer is written onto the Clover order itself. It does not change which puzzle is printed.

06

One switch

Turn printing off without losing the packs you activated.

INSTALL

Price & installation

\$0.99 / month

↓ **Install on Clover App Market** (<https://www.clover.com/appmarket/apps/PAKJ4G4QSB3BA>)

Every app has a 30-day free trial. Clover bills the subscription with your monthly Clover invoice.


How to install

1. Open the **Clover App Market** — on the device, or at `clover.com/appmarket` in your web dashboard.
2. Find the app by name, or open its direct link from the button above.
3. Tap `Connect` / `Install` and accept the permissions the app requests.
4. The 30-day free trial starts automatically. The subscription then appears on your monthly Clover invoice.
5. Open the app on the Clover device and sign in with a **Manager** or **Admin** employee account to configure it.
6. To cancel later, uninstall the app from the App Market — the steps are right below.

How to cancel the subscription


Cancelling means uninstalling the app — there is no separate billing screen.

1. Open the **App Market** — on the Clover device, or in the web dashboard.
2. Open **My Apps**. Every app you pay for is listed there with its monthly fee.



App name	Developer	Fee	Actions
Actions: Automate items, fees, d...	PayFlare	\$1.99/month	⋮
Age Verify	PayFlare	\$0.99/month	⋮
Auto Item: Automate fees, items, ...	PayFlare	\$0.99/month	⋮
Contacts On Receipts	PayFlare	\$0.99/month	⋮
Cost Discounts	PayFlare	\$0.99/month	⋮
Customer Assigner (+ Tax Exempt)	PayFlare	\$0.99/month	⋮
Customer Discounts	PayFlare	\$0.99/month	⋮

3. Tap the ⋮ button on the app's row and choose **Uninstall app**.
4. The app's own page works too: ⋮ next to the green **Open the app** button → **Uninstall app**.



5. Confirm. The subscription stops there and then — the app is off your next Clover invoice.


Install and cancel any time from the Clover App Market.

START HERE


First setup

Do this once, in this order. It takes a few minutes and the app is then ready for the shift.


1. Open **Games On Receipts**; the packs are listed with a short description.



2. Tap **AVAILABLE** on a pack and confirm with **Activate** — the app downloads that pack's puzzles.
3. Open a pack to see its puzzles. Tap a puzzle to see it full size.



4. Open **Settings** and check that **Print on receipts (random games)** is on — it is on by default.



5. Serve a customer and check the printed receipt.

CONFIGURATION

Setup scenarios

Each scenario is a complete configuration — follow the steps in order.

Most configuration screens require the Clover employee role of Manager or Admin.

1 Print a random puzzle on every receipt

The simplest setup: turn it on and the receipts do the rest.

1. Open **Games On Receipts** — the packs **Mazes**, **Sudoku** and **Tic Tac Toe** are listed.
2. Tap **AVAILABLE** on a pack and confirm with **Activate** — the app downloads that pack's puzzles.
3. Open a pack to see the individual puzzles and their previews.
4. Open **Settings** and check that **Print on receipts (random games)** is on — it is on by default.
5. Serve a customer and check the printed receipt.

Puzzles make receipts longer. If paper cost matters, activate fewer packs or print on demand only.

2 Print a puzzle on request

A family with children at the table, or a customer who has to wait.

1. Turn **Print on receipts (random games)** off in Settings if you do not want it on every receipt.
2. Open the pack you want, for example **Mazes**.
3. Find the puzzle in the list — the thumbnails are faded; tap one to see it full size.
4. Tap its **PRINT** button — a **Printing..** message appears while the puzzle is downloaded and sent to the receipt printer.
5. Hand it over with the order.

3 A campaign built around one pack

A loyalty or kids' club promotion that uses a single pack of puzzles.


1. Activate the pack you use for the campaign.
2. Print manually, or leave random printing on for the duration of the campaign.
3. To record the customer on each order, open **Settings** and turn on **Assign customers in the Register app**.
4. When the first item is rung up, a customer search opens — pick the customer to attach them to the order. This does not change which puzzle is printed.
5. When the campaign is over, tap the pack's green **ACTIVATED** button and confirm **Delete**. This deletes the downloaded puzzles from the device; they download again if you activate the pack later.

REFERENCE

Screens and settings

Every screen of the app and what each setting does. (4)

Packs



Pack card

The pack name and what it contains, e.g. `11 maze games for your customers`.

AVAILABLE

Downloads the pack's puzzles and activates it. A dialog asks you to confirm with `Activate`.


ACTIVATED

The green state: the pack is on. Tap it to switch the pack off — a dialog asks you to confirm `Delete`, and the downloaded puzzles are removed from the device. Activating the pack again downloads them back.

Gear

Opens Settings.

Inside a pack



Puzzle preview

A faded thumbnail of the puzzle. Tap the card to open the puzzle full size.

Puzzle name and hint

E.g. Maze 1 · Find a way out of the maze .

PRINT

Prints this specific puzzle right now. A **Printing..** message appears while the puzzle is downloaded, so an internet connection is needed.

Puzzle view

Full-size puzzle

Opens when you tap a puzzle card. This view shows the puzzle as it will be printed; the thumbnails in the list are faded.


Puzzle name

The name of the puzzle, on the white bar under the picture.

Green print button

Prints this puzzle. A **Printing..** message appears while it is downloaded and sent to the receipt printer.

Settings



Print on receipts (random games)

Master switch for random printing. Keep at least one pack activated while it is on; if you want no puzzles at all, turn the switch off instead of leaving it on with no pack activated.

App version

The installed version.

Contact us

Shows PayPlaxe support contacts — email, WhatsApp/SMS and a QR code.

Assign customers in the Register app

When on, a customer search opens once per order after the first item is added. The customer you pick is written onto the Clover order, so the order shows that customer everywhere in Clover. It has no effect on which puzzle is printed. If you also run the Customer Assigner app, leave this switch off — otherwise both apps ask for the customer on the same order.

AT THE REGISTER

Everyday use

What the cashier does after the app is configured.

1. With random printing on, nothing to do — puzzles appear on receipts by themselves.
2. To hand a specific puzzle to a waiting family, open the pack and tap its PRINT button. This needs an internet connection.
3. Turn the switch off during busy hours if receipt length matters.

IF SOMETHING IS WRONG

Troubleshooting

Symptom on the left, what to do on the right.

No puzzle is printed.

Print on receipts (random games) is off, or no pack is activated. Random printing needs at least one activated pack — activate one, or turn the switch off if you do not want puzzles.

Receipts became too long.

Activate fewer packs, or switch random printing off and print on demand only.

The same puzzle repeats.

The app picks one of your activated packs at random, then a puzzle inside it, so a pack with few puzzles repeats often. Activate a pack with more puzzles, such as **Mazes**, or switch off a one-puzzle pack such as **Tic Tac Toe**.

The pack list is empty.

The app needs an internet connection every time it loads the packs. Check the device's connection and open the app again.

The app's dialog never appears on the payment screen; Clover shows "Customer is choosing payment method".

Open the Clover **Setup** app → **Payments** and uncheck **Automatically take payment on Connected Device**, so payment is taken on the primary device.

Settings cannot be opened or changed.

Sign in with an employee whose Clover role is **Manager** or **Admin**. Some apps also have their own **Restrict access** switch that locks the configuration.

The app works erratically, or stops reacting after the device has been idle.

Turn off Battery Saver in the device's Android settings and keep the device online.

A change made on one device is not visible on another.

Settings sync through the cloud; give it a minute and make sure both devices have a network connection.

QUESTIONS

FAQ

Where do the puzzles come from?

From ready-made packs provided by PayPlaxe — Mazes, Sudoku and Tic Tac Toe. Activating a pack downloads its puzzles to the device. The device needs an internet connection to open the app, to browse a pack and to use **PRINT**; only automatic printing on receipts keeps working offline, because it reads the puzzle files already downloaded.

Can I print a specific puzzle?

Yes — printing can be manual instead of random.

Does it make receipts much longer?

A puzzle adds height to the receipt. Print manually if paper cost is a concern.

Can I turn it off temporarily?

Yes, disable printing in Settings; your activated packs stay.

How much does it cost?

\$0.99 per month, with a 30-day free trial.

SUPPORT

Contacts

EMAIL

contact@payplaxe.com

TEXT MESSAGE

[743-800-4077](tel:743-800-4077)

WEBSITE

payplaxe.com (<https://payplaxe.com>)

IN-APP SUPPORT

Settings → Contact us

ANSWER TIME

5–15 minutes

Unofficial documentation set generated for PayPlaxe Clover POS apps. Prices and features follow the published product pages.

contact@payplaxe.com payplaxe.com (<https://payplaxe.com>)

[Clover Apps \(US\)](https://www.clover.com/appmarket/developer/851YWYC4PW440) (<https://www.clover.com/appmarket/developer/851YWYC4PW440>)

[Clover Apps \(EU\)](https://www.eu.clover.com/appmarket/developer/FBG7E8TY6C95W) (<https://www.eu.clover.com/appmarket/developer/FBG7E8TY6C95W>)